


FERMAX

VDS BASIC iLOFT TELEPHONE


MANUAL DE USUARIO USER'S MANUAL MANUEL D'UTILISATION BENUTZE
MANUAL DO USUÁRIO MANUAL DE USUARIO USER'S MANUAL MANUEL D'
HANDBUCH MANUAL DO USUÁRIO MANUAL DE USUARIO USER'
UTILISATION BENUTZERHANDBUCH MANUAL DO USUÁRIO MA
UAL MANUEL D'UTILISATION BENUTZERHANDBUCH MANUAL
INSTALADOR INSTALLER'S MANUAL MANUEL D'INSTALLATION
ONSHANDBUCH MANUAL DO INSTALADOR MANUAL DE INSTAL
S MANUAL MANUEL D'INSTALLATION INSTALLATIONSHANDBUC
INSTALADOR MANUAL DE INSTALADOR INSTALLER'S MANUA
STALLATION INSTALLATIONSHANDBUCH MANUAL DO INSTALA
USUARIO USER'S MANUAL MANUEL D'UTILISATION BENUTZE



USER'S MANUAL

ENGLISH

iLOFT TELEPHONE OPERATION

**Buttons**

 Lock Release / Call Guard Unit Button



Pressing this button activates the lock-release. The door can be opened at any time.

When you press this button with the telephone on the hook, a call will be made to the guard (*where one exists).



Audio activation, hang up and auto-start button.

On receiving a call the user has 30 seconds to answer. The blue led flashes during this time to indicate a call waiting.

- *Audio activation*: when a call is received, press and release this button to speak to the visitor. The audio channel between the entry panel and the residence is opened; operating in hands-free mode. The blue led will remain on indicating that a conversation with the entry panel is underway.
- *Hang-Up*: press to end communication, if not the conversation will be disconnected after 90 seconds. Once disconnected the blue led will turn off.
- *Auto-start (main panel)*: on standby, press and release this button (the blue led lights up).

Note:

- *The conversation is private, no other terminal can hear it.*
- *«Handsfree» mode is default mode.*
- *While the audio channel is open the input audio can be regulated with the potentiometer, without affecting the call volume. The selected setting will not be altered if the call volume is subsequently adjusted.*
- *If the channel is busy an error tone «BEEP» will be generated and auto-start will not activate.*
- *If the telephone is configured in «simplex mode», (press to speak and release to listen), the audio channel will be activated to hear sound at street level.*
- *The auto-start function is always used on the main panel except where a call is received on the secondary panel. Once the conversation is over auto-start will activate on the secondary panel for 30 seconds. After this time it will activate on the main panel.*
- *During the conversation «handsfree» can be adjusted to «simplex mode».*

F1 F1: Button for Additional Functions.

No function in this model.

Led Signals

STATUS (Telephone)	Blue Led 	Green Led 	Red Led
Not programmed	very slow intermittent		
Standby			
Call	rapid intermittent		
Handsfree audio	constant		
Output Audio (simplex mode)	constant		
Input Audio (simplex mode)	slow intermittent		
Do not Disturb			constant
Auto Opening (Doormatic)		slow intermittent	
Select Ringtone Panel 1			slow intermittent
Select Ringtone Panel 2			rapid intermittent
Address Programming	constant		constant

AVAILABLE FUNCTIONS

- Door Opening and Automatic Door Opening (DOORMATIC)
- Call to Guard (where one exists)
- Call volume regulation (8 levels)
- Call Disconnection (Do not Disturb)
- Ringtone Selection (5 options)
- Doorbell
- Programming via the terminal and via the entry panel
- Input audio volume regulation


Operation

Answering a call.

When the call button on the **entry panel** is pressed a call tone is emitted both from the entry panel and the telephone.

On receiving a call on the telephone the user has 30 seconds to answer. The blue led flashes during this time to indicate a call waiting.

- **Audio activation:** When a call is received, press and release $\mu\zeta$ button to speak to the visitor. The audio channel between the entry panel and the residence is opened; **operating in hands-free mode**. The blue led will remain on indicating that a conversation with the entry panel is underway.
- **Hang-Up:** press $\mu\zeta$ to end communication, if not the conversation will be disconnected after 90 seconds. Once disconnected the blue led will turn off.
- **Auto-start (main panel):** while on standby, press and release $\mu\zeta$ button (the blue led lights up).



While in simplex conversation mode (press the $\mu\zeta$ button to speak and release to listen).

When the call button on the **Entry Panel** is pressed a call tone is emitted both from the entry panel and the telephone.


On receiving a call on the telephone the user has 30 seconds to answer. The blue led flashes during this time to indicate a call waiting.

- Press and release the $\mu\zeta$ button, the blue led will continue to flash, the input audio will remain active (you will hear the panel on the telephone).


From this point every time you press the $\mu\zeta$ button, the output audio channel will activate (you will hear the telephone on the panel) and a constant blue led will light up.

On releasing the $\mu\zeta$ button the input audio channel will activate (you will hear the panel on the telephone) and the intermittent blue led will light up.

- **Hang-Up:** press $\mu\zeta$ to end communication, if not the conversation will be disconnected after 90 seconds. Once disconnected the blue led will turn off.
- **Auto-start (main panel):** with the telephone on standby, press and release this button $\mu\zeta$ (short press), the blue led lights up (indicates simplex mode).



audio channel audio channel
Entry Panel - Residence Residence - Entry Panel





Opening the Door

When a call is received from the entry panel, you can open the door at any time, by pressing the button

«Automatic Opening» (DOORMATIC) Mode

With «Automatic Opening» **activated**, when a call is received from the entry panel, the lock-release is activated once the ringtone stops.

The open door function is disabled by default. It must be **pre-enabled** (by the installer), **to be able to be activated** by the user.



1. To **activate** the function, you must hold down the button and button simultaneously until you see the green light flashing.


Once this is activated the door will automatically open when a call is received.

2. To **deactivate** the function, you must hold down button and button simultaneously until you see the green light turn off.

Important Note:

- The automatic door function **CANNOT** be activated if it has not been previously enabled.

Canceling the Ring Tone



If during call volume regulation the potentiometer is turned down to its minimum level, a constant red led will light up to indicate that the call has been disconnected.

The disconnection option affects all ringtones generated by the telephone:

To deactivate ringtone cancellation, you must move the potentiometer above the minimum level. The led will return to its previous status.

Note:

- The blue led flashes when a call is being received whether enabled or not.
- For more operating information: See «**Call Volume Regulation**».

FERMAX