

## AJUSTE DE TONO Y CANCELACIÓN DE LLAMADA EN MONITOR LOFT COMPACT

MONITOR **NO** RECIBE LLAMADA: **LED ROJO PARPADEA**  
MONITOR RECIBE LLAMADA: **LED ROJO ENCENDIDO FIJO**

1. Pulsar el botón **MENÚ** durante 5 segundos. *El led rojo parpadea 1 vez por segundo y se escucha un sonido de confirmación.*
2. Pulsar de nuevo el botón **MENÚ**.
3. Pulsar botón **+** para cambiar el tono de llamada o Pulsar botón **-** para que no suene la llamada.
4. Pulsar el botón **MENÚ** dos veces.

\* Más información en [www.fermax.com](http://www.fermax.com) (ref. 3753).

## AJUSTE DE TONO Y CANCELACIÓN DE LLAMADA EN MONITOR LOFT COMPACT

MONITOR **NO** RECIBE LLAMADA: **LED ROJO PARPADEA**  
MONITOR RECIBE LLAMADA: **LED ROJO ENCENDIDO FIJO**

1. Pulsar el botón **MENÚ** durante 5 segundos. *El led rojo parpadea 1 vez por segundo y se escucha un sonido de confirmación.*
2. Pulsar de nuevo el botón **MENÚ**.
3. Pulsar botón **+** para cambiar el tono de llamada o Pulsar botón **-** para que no suene la llamada.
4. Pulsar el botón **MENÚ** dos veces.

\* Más información en [www.fermax.com](http://www.fermax.com) (ref. 3753).

## AJUSTE DE TONO Y CANCELACIÓN DE LLAMADA EN MONITOR LOFT COMPACT

MONITOR **NO** RECIBE LLAMADA: **LED ROJO PARPADEA**  
MONITOR RECIBE LLAMADA: **LED ROJO ENCENDIDO FIJO**

1. Pulsar el botón **MENÚ** durante 5 segundos. *El led rojo parpadea 1 vez por segundo y se escucha un sonido de confirmación.*
2. Pulsar de nuevo el botón **MENÚ**.
3. Pulsar botón **+** para cambiar el tono de llamada o Pulsar botón **-** para que no suene la llamada.
4. Pulsar el botón **MENÚ** dos veces.

\* Más información en [www.fermax.com](http://www.fermax.com) (ref. 3753).

## AJUSTE DE TONO Y CANCELACIÓN DE LLAMADA EN MONITOR LOFT COMPACT

MONITOR **NO** RECIBE LLAMADA: **LED ROJO PARPADEA**  
MONITOR RECIBE LLAMADA: **LED ROJO ENCENDIDO FIJO**

1. Pulsar el botón **MENÚ** durante 5 segundos. *El led rojo parpadea 1 vez por segundo y se escucha un sonido de confirmación.*
2. Pulsar de nuevo el botón **MENÚ**.
3. Pulsar botón **+** para cambiar el tono de llamada o Pulsar botón **-** para que no suene la llamada.
4. Pulsar el botón **MENÚ** dos veces.

\* Más información en [www.fermax.com](http://www.fermax.com) (ref. 3753).

CALL TONE SELECTION AND CALL CANCELLATION OF LOFT COMPACT MONITOR

MONITOR DOES NOT RECEIVE CALL: **RED LED BLINKS**

MONITOR RECEIVES CALL: **RED LED ON**

1. Press the **MENÚ** button for 5 seconds. The red LED blinks once per 5 second and a confirmation tone is heard.
2. Press the **MENÚ** button again.
3. Press the **+** button to change the monitor Call Tone or  
Press the **-** button to activate Call Cancellation.
4. Press the **MENÚ** button twice.

*\* More information en [www.fermax.com](http://www.fermax.com) (ref. 3753).*

CALL TONE SELECTION AND CALL CANCELLATION OF LOFT COMPACT MONITOR

MONITOR DOES NOT RECEIVE CALL: **RED LED BLINKS**

MONITOR RECEIVES CALL: **RED LED ON**

1. Press the **MENÚ** button for 5 seconds. The red LED blinks once per 5 second and a confirmation tone is heard.
2. Press the **MENÚ** button again.
3. Press the **+** button to change the monitor Call Tone or  
Press the **-** button to activate Call Cancellation.
4. Press the **MENÚ** button twice.

*\* More information en [www.fermax.com](http://www.fermax.com) (ref. 3753).*

CALL TONE SELECTION AND CALL CANCELLATION OF LOFT COMPACT MONITOR

MONITOR DOES NOT RECEIVE CALL: **RED LED BLINKS**

MONITOR RECEIVES CALL: **RED LED ON**

1. Press the **MENÚ** button for 5 seconds. The red LED blinks once per 5 second and a confirmation tone is heard.
2. Press the **MENÚ** button again.
3. Press the **+** button to change the monitor Call Tone or  
Press the **-** button to activate Call Cancellation.
4. Press the **MENÚ** button twice.

*\* More information en [www.fermax.com](http://www.fermax.com) (ref. 3753).*

CALL TONE SELECTION AND CALL CANCELLATION OF LOFT COMPACT MONITOR

MONITOR DOES NOT RECEIVE CALL: **RED LED BLINKS**

MONITOR RECEIVES CALL: **RED LED ON**

1. Press the **MENÚ** button for 5 seconds. The red LED blinks once per 5 second and a confirmation tone is heard.
2. Press the **MENÚ** button again.
3. Press the **+** button to change the monitor Call Tone or  
Press the **-** button to activate Call Cancellation.
4. Press the **MENÚ** button twice.

*\* More information en [www.fermax.com](http://www.fermax.com) (ref. 3753).*