




# M Ó D U L O TELECÁMARA

## CONEXIÓN DEL MÓDULO

El Módulo Telecámara permite conectar cómodamente los cables necesarios, gracias a sus conectores extraíbles.

También es interesante el *Conector de Test* que incorpora: una vez cableada, al insertar el conector hembra del monitor en la telecámara la imagen aparece directamente en el monitor. Así podemos comprobar el correcto funcionamiento de ambos dispositivos.



Detalle del Test de Monitor y Telecámara

Cod.94161 V07/03

El Módulo Telecámara para placas **FERMAX** antivandálicas es necesario para instalaciones de videoportero.


Este módulo es fabricado con tecnología CMOS, e incorpora una óptica de 3,6mm gran angular, batería de leds infrarrojos para visión nocturna y Pan & Tilt (ver detalle).

## MONTAJE DEL MÓDULO

¡NO INSTALE ÉSTE MÓDULO SIN ANTES HABER COLOCADO LOS MÓDULOS DE PULSADORES!

Encaje el módulo telecámara en la ventana del marco y presione manualmente ambos lados del módulo hasta oír un 'clic'.

¡EL MÓDULO TELECÁMARA SE INSERTA SIN NINGÚN TIPO DE HERRAMIENTA!



Ejemplo de cableado del módulo a monitores



# TELECAMERA MODULE

Cod.94161 V07/03

The telecamera module for **FERMAX** vandal-resistant panels is necessary for every video-door entry system.

This module is manufactured with CMOS technology, includes a 3.6mm wide angle optic, infrared led matrix for night use and Pan & Tilt (see detail).

## MODULE INSTALLATION

⚠DO NOT INSTALL THIS MODULE BEFORE THE PUSHBUTTONS MODULES HAVE BEEN INSTALLED!

Insert the telecamera module in window and push down both sides manually until a 'clac' is heard.


⚠THE TELECAMERA MODULE MUST BE INSERTED WITHOUT ANY TOOL!




## MODULE CONNECTION

The telecamera module allows to connect the wires needed comfortably, by means of its removable connectors.

The *Test Connector* is another interesting feature built in the telecamera: once it has been connected, if the female connector in the monitor is plugged into the telecamera the image appears automatically in the monitor. This allows to test the right operation of both devices.



Monitor and Telecamera Test detail



Connection example of module to monitors