


REPLACING A WAY MONITOR

- Install extra monitor **Ref.1405/1412** (monitor 1) or **Ref.1406/1413** (monitor 2)
- Go to **MENU** Screen & press **ABOUT** button
- Hold press **KEY** button for **2 seconds**




- In the **INSTALLER SETUP**
*NOTE: Extra monitors are always programmed as **SLAVE** from factory and they show always video when receiving an incoming call.*
*There must be always one **MASTER** in the same house (1 master maximum).*
*For **MASTER** - Dial **8000** and press OK*
*For **SLAVE** - Dial **8001** and press OK*
 - Dial **8006** in case you want to have video+call signal in **SLAVE** monitor
 - Dial **8007** to not have video+call signal in **SLAVE** monitor



Important note: Batteries. This equipment contains a lithium button cell CR1120 3V 40mAH welded to the circuit. This button cell must be removed by a qualified professional and taken to the proper disposal site.

REPLACING A WAY MONITOR

- Install extra monitor **Ref.1405/1412** (monitor 1) or **Ref.1406/1413** (monitor 2)
- Go to **MENU** Screen & press **ABOUT** button
- Hold press **KEY** button for **2 seconds**




- In the **INSTALLER SETUP**
*NOTE: Extra monitors are always programmed as **SLAVE** from factory and they show always video when receiving an incoming call.*
*There must be always one **MASTER** in the same house (1 master maximum).*
*For **MASTER** - Dial **8000** and press OK*
*For **SLAVE** - Dial **8001** and press OK*
 - Dial **8006** in case you want to have video+call signal in **SLAVE** monitor
 - Dial **8007** to not have video+call signal in **SLAVE** monitor



Important note: Batteries. This equipment contains a lithium button cell CR1120 3V 40mAH welded to the circuit. This button cell must be removed by a qualified professional and taken to the proper disposal site.

تعويض جهاز العرض WAY

- قم بتركيب جهاز العرض الإضافي رمز 1405 /1412 (جهاز العرض 1) أو رمز 1406/1413 (جهاز العرض 2)
- على شاشة قائمة الخيارات، اضغط على زر حول
- اضغط على زر المفتاح لمدة ثانيتين 2



في تكوين المركب P

- ملاحظة: يتم توفير أجهزة العرض الإضافية دائما مُبرمجة كتابع من المصنع وتُظهر فيديو خلال المكالمة. يجب دائما وجود جهاز رئيسي في المنزل (جهاز رئيسي 1 كحد أقصى) للجهاز الرئيسي - سجل رقم 8000 وانقر على OK للجهاز التابع - سجل رقم 8001 وانقر على OK
- سجل رقم 8006 إن كنت تريد الحصول على فيديو + مكالمة على الجهاز التابع
- سجل رقم 8007 إن كنت لا تريد الحصول على فيديو + مكالمة على الجهاز التابع


بطاريات (ملاحظة مهمة)

يحتوي الجهاز على بطارية ليثيوم على شكل بطارية ساعة CR1120 3V 40MAH مثبتة على الدارة الكهربائية عبر اللحام. ويمكن استخراج هذه البطارية من قبل حرفي مختص وإدائها في نقطة التجميع الانتقائي التابع لك.



تعويض جهاز العرض WAY

- قم بتركيب جهاز العرض الإضافي رمز 1405 /1412 (جهاز العرض 1) أو رمز 1406/1413 (جهاز العرض 2)
- على شاشة قائمة الخيارات، اضغط على زر حول
- اضغط على زر المفتاح لمدة ثانيتين 2



في تكوين المركب P

- ملاحظة: يتم توفير أجهزة العرض الإضافية دائما مُبرمجة كتابع من المصنع وتُظهر فيديو خلال المكالمة. يجب دائما وجود جهاز رئيسي في المنزل (جهاز رئيسي 1 كحد أقصى) للجهاز الرئيسي - سجل رقم 8000 وانقر على OK للجهاز التابع - سجل رقم 8001 وانقر على OK
- سجل رقم 8006 إن كنت تريد الحصول على فيديو + مكالمة على الجهاز التابع
- سجل رقم 8007 إن كنت لا تريد الحصول على فيديو + مكالمة على الجهاز التابع

بطاريات (ملاحظة مهمة)

يحتوي الجهاز على بطارية ليثيوم على شكل بطارية ساعة CR1120 3V 40MAH مثبتة على الدارة الكهربائية عبر اللحام. ويمكن استخراج هذه البطارية من قبل حرفي مختص وإدائها في نقطة التجميع الانتقائي التابع لك.

